

ZTE MC7010 5G-Router

Quick Installation Guide

- PoE Injector is labeled in Chinese, so you have to find out first which one is PoE and which is LAN port:
Connect the PoE injector to power and then connect your MC7010 router to one of the 2 injector ports. If MC7010 router starts blinking, this is the PoE port. It's a good idea to mark the PoE port.
- Connect the MC7010 router LAN port to your computer's ethernet port with DHCP enabled.
- Enter <http://192.168.154.1> in your browser. You might select English language in upper right corner.
- The admin password is unique for each router and can be found on first page of Chinese manual. Locate the label sticker in the upper left, the password is printed in last row of this sticker (see image below). There should also be some spare label stickers in the box.



First page of Chinese manual for ZTE MC7010 router with password on label sticker